


Coding Of Erreka Rolling Code Transmitters & Receivers



- 1- Turn Mini Dip-switch on Receiver to ON position
- 2- Press selected channel (button) on Transmitter
- 3- A Beep will be emitted
- 4- Repeat for each new transmitter
- 5- Turn mini dip-switch to off position. (red led will light)